

# IPC CLEAN

*Ion cleaning device to remove static electricity and dust of circuit boards, molded components, and during powdering work.*

**HEPA**  
filter installed

**No need of**  
Compressed air

**350x345<sup>mm</sup>**  
Space saving




Optical equipment



Cosmetic container



Printed-circuit board



Transparent components and films



Chemical powder



Precision molded part

**iON PARTS CLEANER**

Ion Parts Cleaner [IPC CLEAN]

**IPC-250CR**

**RoHS**

# New concept of Ion Cleaning!

## Feature



AC adapter connection terminal and external power supply terminal block are installed on the top.



Built-in HEPA filter.  
Replaceable by unit.

The generated ions are downflowed with the wide air blow.



Power switch

Wind speed  
adjustment trimmer

Pre-filter

High-voltage error  
warning lamp

Ion balance  
adjustment trimmer



Air indicator  
for checking the wind speed

### ■ Clean blower air with HEPA filters

- Clean air with 99.97% of particles of  $0.3\mu\text{m}$  retained by the filter. (Maximum: 25m/s of wind speed,  $1.5\text{m}^3/\text{min}$  of air flow)
- Acrylic resin plate, preventing diffusion of air in the front of the product. (Removable)

### ■ Installation of DC ionizer and creation of neutralization area

- A space 270W x 270D x 250H(mm) is "uncharged".
- The ion balance can be adjusted and the needle electrode can be replaced.
- Warning lamp for high voltage error.

### ■ Air blow speed can be adjusted.

- The amplitude of the wind speed is displayed by a 12-stage LED indicator. This is also a guide for replacing the HEPA filter.
- Minimize this will produce a nearly wind-free state, so it can be used for powder work that is not likely to splash.

### ■ LED illumination


- Lightens your works brightly with LED lamps that can also be used as operating lamps.

### ■ Put the product on the wall surface.

- No protrusions or power terminals installed on the back of the device.  
You can use the workbench space effectively.

### ■ Air circulation type, with no exhausted air.

- The Air is vacuumed up from the pre-filter at the back of the booth passing through the inside blower and is filtered by the HEPA filter, then is blown back from the top of the booth.



## Performance data

### ■ Static elimination performance/noise/wind speed

LED Level	Decay time		Ion balance (±V)	Noise (dBA)	Wind Speed (m/s)
	Negative (sec.)	Positive (sec.)			
1	1.4	1.2	10	52.3	0
3	0.3	0.3	10	52.3	1.0
6	0.2	0.2	10	55	2.0
9	0.2	0.2	10	60	3.0
12	0.2	0.1	10	68	4.0
12(max.)	0.1	0.1	10	73.3	7.0

● Measured on April 12, 2018 at 25°C (temperature) and 45%RH (humidity).  
Decay time, Ion Balance measured with "TREK 158" CPM at 100mm distance from the air outlet.  
Noise measured with "SL-1320" at 1m front.  
Airflow velocity measured with "SK-93F" just below the air outlet.

### ■ Air cleanliness (HEPA filters) <99.9% or more>



Particle	0.3μm	0.5μm	5μm	Total
Primary side	16,165,100	4,884,000	0	21,049,100
Secondary side	420	0	0	420

● Measured on April 13, 2018  
Airflow: Max  
Tested particle: PAO (Polyalphaolefin mist)  
Particulate measured with KC-01DI (primary side, after air passing through the blower) and KC-03B (secondary side, after passing through the HEPA filter)

### ■ Dust removal test

Sample: Bakelite plate (150×90 mm, 3 mm thick)  
Pseudo-contaminant: cotton linter  
Static elimination time: 3 seconds (inclined at 45° with respect to the air outlet)

Before dust removal  
charging voltage:  
+1.25kV



After dust removal  
charging voltage:  
0kV



The white reflective cotton linters have been effectively removed.


● Measured on April 11, 2018 with Electrostatic Field Meter Eye-02, at Max Wind Speed at 26°C (temperature) and 45%RH (humidity)

## Dimensions

### No.IPC-250CR


EDP No. 623201

## RoHS



### APPLICATIONS (Static elimination and dust removal)

- For decomposition and repair of mobile phones and small electronic devices
- Before assembly of various receiving components
- Products before UV processing and silk printing
- Plastic moldings
- Glass substrates and semiconductor devices
- Before product packaging



#### Replacement parts

Pre-filter IPC-250CRPF  
HEPA filter IPC-250CRHF  
Needle electrode SDJ-05RH

#### Option

Power adapter AD24-150-PD4  
EDP 806146  
I/P 100V to 240 V AC, 50/60 Hz  
O/P 24V DC 5A



### ■ Specifications

Model No.	IPC-250CR
Dust collection method	Built-in pre-filter and HEPA filter (two-stage)
Reference work size	A4 size with forward and backward changes, and A5 size without changes
Power supply	24V DC ±5%
Power consumption	108 W max.
Current consumption	4.5 A max. (excluding inrush)
Protective function	Overcurrent protective fuses (250V 3A)
Air flow	Max. 1.5 m³/min (No internal filter clogging, output value of the blower)
Wind speed	Max. 25m/sec. (No clogging of built-in filter, output value of the blower)
Noise	74 dBA (Maximum air flow, no clogging of built-in filter or deterioration of blower)
Operating temperature and humidity	+5 to +40°C 35 to 65% RH (no condensation or freezing)
Size	350W×345D×515H (without protrusions)
Weight	Approx.22 kg
Material	Steel Sheet (Munsell color N9.0, spray-painted finish)
Accessory	Caution label sticker / Instruction manual

### ■ Ionizer



Ionizing method	DC corona discharge type
Number of discharge electrodes	4 pieces (Positive 2 and Negative 2)
Applied voltage	+6kV, -3 to -7kV
Effective static elimination current	300 μA or less
Electrode coupling method	direct coupling
Material of the discharge electrode	Stainless-steel
Ion balance	±30V
Decay time	Within 1 second measured at 100 mm from the air outlet (±1000V→100V)
Alarm output	High-voltage output stop warning (red LED)

### ■ Maintenance time \*It depends on usage conditions.

Pre-filter	1 week (recommended daily cleaning)
HEPA filter	1 year
Discharge needle	1 week



## APPLICATIONS

	Ion cleaning	Removal of charge
<b>Automotive parts</b>	 <p>Substrates, Speedmeter, Needle display parts, etc.</p>	 <p>Emblem, Metal parts (static elimination before hot stamping), Reflector (static elimination before vapor deposition), LCD module (protection film release)</p>
<b>Cellular phone</b>	 <p>Lenses, Component trays, Switches (before the resin plating)</p>	 <p>Cover (before painting), LCD module, Printed circuit board (release of protection film)</p>
<b>Optical Electronics</b>	 <p>Printed circuit boards, Glass lenses</p>	 <p>Touch panel (before silk printing), Remote control button (before pad printing), Plastic lens (before UV processing)</p>
<b>Pharmaceutical</b>	 <p>Dental mirrors, PET medicine bottles, Cosmetic bottles</p>	 <p>Drug trays (before packing), Powder (at the time of balance)</p>
<b>Plastic</b>	 <p>Major appliances, Transparent products</p>	 <p>Insert molded article (before double molding) Metallic coated article (before coating)</p>



Warning

- Be sure to read the instruction manual for safe use of the product. • Do not use the product for any other purpose than static elimination or dust elimination.
- Never expose the product vacuum to fire, explosive dust, or dust-containing liquid mist to prevent fire accidents.
- Never expose the product vacuum to moisture, such as wet dust, water, or oil to prevent product failures and accidents.
- Never use the product in such application to prevent fire accidents, as dust can be mixed inside the product and converted into hazardous materials.
- Usage as a painting booth is prohibited. Do not paint.

Manufactured by

**VESSEL Co., Inc.**

17-25, Fukae-kita 2-chome, Higashinari-ku, Osaka 537-0001 JAPAN  
Tel : +81(0)6 6976 7778 Fax : +81(0)6 6972 9441

●For improvements, the product specifications, size, price and other information may be subject to change without prior notice.

*Distributed by*